

# IP Power 9850XX

## User Manual



**Version: 1.02**

**Firmware Version: 1.29\_710**

**Date Released: August 2022**

**Warning:** Any changes made to this equipment without permission may cause damages to the device!

#### IMPORTANT NOTICE

1. IP Power 9850XX was designed for indoor use, we carry no responsibility for possible damages caused by outdoor use, especially in the rain.
2. Please use the power adapter provided by the dealer, we carry no responsibility for the possible damage from using power adapters not provided by us.
4. Do not shake the IP Power 9850XX in any fashion
5. Please contact the dealer If IP Power 9850XX is not working properly.

Copyright © 2018 All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written consent of us.  
All trademarks and products mentioned in this document are the properties of us.

# Table of Content

<b>1.Introduction .....</b>	<b>4</b>
<b>2.Product Information.....</b>	<b>5</b>
2.1 Features : .....	5
2.2 Specification .....	6
2.3 Minimum System Requirements .....	6
2.4 Package Contents.....	6
2.5 Interface Description .....	7
<b>3. Setting up your device.....</b>	<b>9</b>
3.1 Before Starting.....	9
3.2 Hardware Connection .....	9
3.3 Software Installation .....	10
<b>4.Web Interface .....</b>	<b>15</b>
4.1 Top Column .....	16
4.2 Power Control.....	19
4.3 Network .....	36
4.4 Application Settings.....	39
4.5 System Setting.....	50
<b>5.Other ways to control .....</b>	<b>56</b>
5.1 CGI HTTP Commands .....	56
5.2 Telnet Control.....	58
<b>6.FAQ : .....</b>	<b>59</b>

# Welcome

## 1.Introduction

IP Power 9850XX is a new generation of the Power Distribution Unit (PDU) & Remote Power Control (RPC) system.

With embedded web server and **HTTPS** protection , 9850XX supports higher grade security as working on Internet. User can control power easily and more safely through the web browser in Windows , Android or iOS system , like Internet Explorer (IE) , Google Chrome , Safari web browser or control through APP in Android or in iOS system .

With 4 buttons on device top, it allows user to direct control manually to each port ON/OFF with fingertip without web browser / APP , also allows remote control power on/off up to **4 separate** devices via network .

As support **SSL & SNMP**, user can use public email like Gmail / Hotmail / Yahoo Mail to get the email as the ON/OFF status changed . User can also **control** by **e-mail** without doing port forwarding / port mapping and search the other IP Device in webpage directly and quick .

9850XX supports **Auto Ping , Time Scheduler** which is more suitable for factory / commercial / office / home automation . User can get the device status in LOG information or in remote IP address which sent to get LOG message from 9850 ( SYSLOG ) . .

UPNP \*\*

For system integrator, there are several popular developing tolls like HTTP/CGI command , **SSH/Telnet , SNMP** , Modbus TCP/IP & BACnet TCP/IP .

The various applications of the 9850XX includes:  
Power Management, Server Management, Internet Controllable Timer,  
**System Integration, Remote Power Control in Remote locations etc.**

User Friendly . Convenience & Powerful ,

\* MQTT 1.3.1 Cloud IoT protocol - supports  
Cloud IoT Server of Microsoft AZURE , Google Cloud IoT & Amazon AWS IoT

\*\* UPNP -- No need to do " port forwarding " from router , simply enter webpage via Wan  
( user's router need to support UPNP )




## 2.Product Information

### 2.1 Features :

1. 4 port Remote power controller for power On, Off and Reboot.
2. Web Server built-in design, directly control by web browser in Windows , **Android or iOS** system like Internet Explore (IE) , Google Chrome and so on .
3. **4 Buttons Control** : Direct manual hardware control each outlet without working on Web browser .
4. Support **HTTPS** , SSL , TCP/ IP , DHCP, DDNS , SMTP , **SSH/Telnet** , **SNMP** , Modbus/TCP and BACnet/IP.
5. Power Surge protection & FUSE embedded in
6. **SYSLOG** : Support Log function & send to assign IP address
7. Time Schedule - can pre-set a suitable time to turn power on / off automatically.
8. **Auto Ping** for network control & segment management automatically
9. High grade components for long stability and performance
10. **Back Up** for quick setup for multiple devices like Time Schedule, Network Setting.
11. Support public e-mail -- @gmail.com , @yahoo.com , @hotmail. com.....etc.  
**E-mail Control & Advice** :  
 - Receive e-mail with IPs device boot up.  
 - **POP3 Control**–Control each outlet ON/OFF via E-mail. No need to do Port Forwarding .
12. Specific software developed by Aviosys and provided free of charge :  
 - SDK Available : HTTP Command  
 - Windows software “ IP Power Center “ : Control Multiple Aviosys IP Power devices in one software  
 - CNT software ( Cross Network Technology )- allows user eliminate set up work on any Router without port forwarding , simply Plug & Play .  
**- Support MQTT protocol.**
13. 7 models for different power plugs available  
 - IP Power 9850-FR - France ( NF C61-31)  
 - IP Power 9850-UK - United Kingdom ( BS1363 )  
 - IP Power 9850-GE - German (Schuko )  
 - IP Power 9850-AU – Australia (AS/NZS 3112)  
 - IP Power 9850-US - USA (NEMA5-15R )  
 - IP Power 9850-SW - Switzerland (SEV 1011)  
 - IP Power 9850-DK - Demark ( Type D )
15. Support APP for Android or iOS system :  
 - **Android APP** -- name “IP Power “ free download in Google Play .  
 - **iOS APP** -- name “IPPOWER+ “ free download in Apple App Store

Instant Plug and Play.....  
7 Global Socket Types.....



IPPOWER+  
Aviosys Inc


## 2.2 Specification

- Power input : 15A / 90-120VAC , 10A / 210-240VAC , 50-60Hz.
- Maximum loading of each output: **10Amp**
- Maximum of Total loading : **10Amp**
- Fuse protection : **10Amp**
- Dimensions: 200 x 140 x 50 mm ( L x W x H )
- Weight: 990g
- Enclosure – Metal case in deep Gray color
- Operation **Temperature** : -10 ~ 60 °C or 14 ~104(°F)

## 2.3 Minimum System Requirements





- Network & Web Browser & Internet Connection
- Ethernet Cable & Power Cord


## 2.4 Package Contents

<p>9850XX Unit x 1</p>	 <p>The image shows a black IP Power 9850 power distribution unit. It features four white outlets on the front, numbered 1, 2, 3, and 4 from right to left. Above each outlet is a power button, also numbered 1, 2, 3, and 4. The unit has a power cord on the left side and an Ethernet port on the right side. Text on the unit includes 'IP Power 9850' at the top, 'Each output 10A max, Total output 10A max.' at the bottom, and 'IP Power 9850' on the left side.</p>
<p>Guide for online CD direction : include software QI and manual</p>	

## 2.5 Interface Description


### Outlook

 <p>The above picture are model 9850AU / 9850FR</p>	 <p>9850FR</p>
 <p>The above picture are model 9850GE / 9850UK</p>	 <p>9850UK</p>
<p><b>Buttons Control</b></p>	<p>There are 4 buttons . As outlet turn ON , the buttons light will be ON</p> <p>RESET function : Please keep pressing the two buttons #1 and #2 for 7 seconds and then release .Then you will hear a long beep sound and 3 short beep sound which show the reset Successfully . After reset , all the settings will be back to Default .</p>
<p><b>4 Outlets</b></p>	<p>There are 7 models</p> <ul style="list-style-type: none"> <li>- 9850FR ( NF C61-31)</li> <li>- 9850GE (Schuko )</li> <li>- 9850US (NEMA5-15R )</li> <li>- 9850-DK</li> <li>- 9850UK ( BS1363 )</li> <li>- 9850AU (AS/NZS 3112)</li> <li>- 9850SW (SEV 1011)</li> </ul>
<p><b>Power input</b></p>	<p>In this socket, there is power input and Fuse socket .</p> <ul style="list-style-type: none"> <li>● The input power sends power to the 9850XX.</li> <li>● <b>Fuse</b> : To prevent electrical surges from damaging the unit. The 9850XX comes with one spare fuse in the unit.</li> </ul> <p><b>Fuse TYPE:</b> U/C GFE 10A 250V (PF)</p>

	
<b>Power Switch:</b>	The Power switch turns on the input power.
<b>Network: LAN</b>	LAN 10/100 Mbps network

## Fuse replacement

1.) The fuse is located between the power switch and the power input plugs.




2.) Carefully remove the fuse holder with a flat screwdriver.



3.) The fuse can be purchased from electronic shops.

Specification : U/C GFE 10A 250V (PF)





## 3. Setting up your device

### 3.1 Before Starting

\*Before setting up the device make sure of the following:

- 1.) All the package contents are all included if anything is missing please contact the dealer where the device was purchased from.
- 2.) Check the power input cable is working correctly.
- 3.) Check all cables to make sure there are no problems with it.

### 3.2 Hardware Connection

**Before hardware connection, please make sure that there is no more than 2 network card ( include dynamic network card ) . If there are more than two networkcard in your PC. You may not get the IP address of 9850XX**

The default setting for 9850XX to get IP is DHCP mode - get IP form Router. If user do not use router and connect the 9850XX to your PC directly or connect to HUB which have no DHCP function , the connection sequence of network cable and power cord are different . Please refer following procedure :

#### A. 9850XX ----- Router ----- PC ( with Web browser )

- 1.) Connect the Ethernet cable (RJ45) to the 9850XX to your local area network.
- 2.) Then connect the power cable into the power input port of the 9850XX.
- 3.) Connect the device that you would like to control to the output plug on the top of the 9850XX.
- 4.) Switching the power source to ON status, this switch is located at the rear of 9850XX.
- 5.) After power on for around 45 seconds, there is a short beep sound for 9850XX which means the system reboot successfully

#### B. 9850XX ----- PC ( with Web browser )

If you select to connect to PC directly , please connect the RJ45 cable to 9850XX after 1 minutes as power on of the 9850XX device . power hear the beep sound of 9850XX DO NOT connect the RJ45 as power ON

- 1.) Connect the power cable to 9850XX and press the power switch to ON

- 2.) After 9850XX power on for around 45 seconds , there is a short beep sound for 9850XX which means the system reboot successfully
- 3.) Then Connect the Ethernet cable (RJ45) to the 9850XX to your PC.

**Notice : This is very important for this procedure . Please do not plug the network cable to 9850 first under this connection . ( without Router assigned the IP to 9850 )**

- 6.) Execute the software IPEDIT.exe to get the IP as 192.168.1.169
- 7.) Please make sure the IP address of you PC is also 192.168.1.X / XX/XXX or you may not log in the 9850XX webpage in 192.168.1.169

### 3.3 Software Installation


Please Go to [www.aviosys.com/cd](http://www.aviosys.com/cd) . The note with this online CD link comes with the package .

#### IP Power Software:


IP Edit ( Required)  
 IP Power Center \*( For multiple IP Power devices control purpose )



- 1.) Select the IP Power 9850XX



- 2.) All the available downloads for the 9850XX will be shown
- 3.) Download the required software – **IPEdit.exe** - by clicking on the download button.



Then you can select to connect 9850XX.

### 3.3.1 LAN connect by IP Search software “ **IPEDIT** “



IP Edit is a search tool designed to search, configure, or access the IP Power 9850XX from a local networked computer.

#### IP Power 9850XX Default Login / Password

**Default IP:** 192.168.1.168 ( if there is no DHCP router assigned IP )  
**Default Login username :** admin  
**Default Password:** 12345678

- 1.) In the local devices section user will see user device show up if connection correctly.



## Notice :

### If can't see the IP in the area of Local Devices of IPEDIT.exe. Please check the following situation

1. **Boot up successfully:** Please reboot the 9850XX and check if there are 1 short beep after 1 minutes. This beep means the device boot up successfully . If not , the device may have issue.
2. **Network card :** Please check if there are more than two network card – include wire / wireless / dynamic - in the PC which used IPEDIT software . IPEDIT only support single network PC , please disable the other network connection / functions.
3. **Anti Virus software / Firewall :** Please turn off the antivirus software firewall temporary.
4. **Power :** If there is no power go to 9850XX , please check the fuse part . There will be no power for 9850XX if the fuse buttons is pop up - not easy/flexible to press as it was – by over loading for long time , please press the fuse back and the power will go to 9850XX to boot up .
5. **Connection :** (1) Please make sure that the 9850XX is under same router with the PC used IPEDIT . It is fine to connect across multiple routers but it need to setup the MASK part which need some knowhow .  
2.) Select the 9850XX device and the device information will pop up on the right.  
3.) Check to see that the gateway IP and the IP Address (9850XX) match user current network.

If not, type in the correct information, then hit the submit button to save changes.

*For example:*

*If user have the following information regarding the 9850XX and user network*

#### **User PC Network :**

**Computer IP Address:** 192.168.1.122

**Gateway:** 192.168.1.1

**Sub Net mask:** 255.255.255.0

**Port:** 80

#### **User 9850XX in IPEDIT :**

**9850XX IP Address:** 192.168.100.34

**Gateway:** 192.168.100.1

**Sub Net mask:** 255.255.0.0

**Port:** 80

*Since the IP Address of the 9850XX is : 192.168.100.34*

User will need to make sure that the first 3 segments of user 9850XX IP Address must match the first 3 segments of user gateway IP.

First 3 Segment of Gateway Address: 192.168.1.X

So user new IP Address for the 9850XX should be: 192.168.1.X

#### **New Network Information**

**9850XX IP Address:** 192.168.1.26

**Gateway Address:** 192.168.1.1

**Local Computer IP Address:** 192.168.1.122

**Sub Net mask:** 255.255.255.0



**Port:** 80

- 4.) Press the “ Rescan “ button to see if changes have been made.
- 5.) Double click on the device in the local device section and an IE web browser with the device login will pop up.
- 6.) Type in the default Login and IP Address to enter the device.

Default Login : admin                      Default : 12345678

Notice :

\* User can click " REF " in IEPDIT to auto search proper IP setting for 9850XX. It will take few minutes to show the suggest wizard.



Please click “ APPLY “ as seeing the suggest wizard , click " yes " to ignore the remind message of IP being used and then type the Username and Password to change the IP setting.

**Username : admin**  
**Password : 12345678**

Notice :

# Segment : The first 9 digits of the IP Address .

EX: The IP of user PC is 192.168.100.122. If the “ Local IP Address “ is 192.168.100. x ( X can the value of 1~252 ) , user PC can get into the webpage of 9850XX .

### 3.3.2 Internet Setup


To connect the IP Power 9850XX on Internet, there are two ways

- Setup Port Mapping / Port Forwarding in your router. Please check your Router owner’s manual .
- Use our own software “ IP Power Center “ : Please refer to the “IP Power Center “ manual in software section of [www.aviosys.com/cd](http://www.aviosys.com/cd)


### 3.3.3 Using IP Service

IP Service is a function which allows user to search for the device easily without having to remember long complicated IP address. Instead, if user know the device's name of user IP Power device and user can easily find IP Address with IP Service. **To log in the webpage of 9850XX on Internet , user still need to do the "Port Forwarding " in own router.**

**Before using "IP Service " , please change the device name of user 9850XX to avoid similar name in Host Server.**




- 1.) Open IP Edit and select the server that user's 9850XX is designated to.
- 2.) Hit the Green Connect button on the top of IP Edit.



- 3.) Then type in the 9850XX Name that user have selected for the device and press the Search button.
- 4.) Find user device and double click on the screen and a IE window will pop up connecting to user device.  
\*User device must be Port Forwarded for the login screen to appear.

EX: The 9850XX device name as IP\_POWER , and user can search the device easily :



- 5.) After user have connected to user device, type in the Login and Password for user device

## 4. Web Interface

Once the 9850XX has been setup correctly, log into the device.

### The default Username and Password for the 9850XX

**Username:** admin

**Password:** 12345678

The Control Console

The Right side Menu of the Web Interface control the functionality and setup of the IP Power 9850XX.



The IP Power 9850XX Console consists of six main sections which will be explained in details below.

**Top Column :** Device name & Column Display ( for smart phone application ) & Time Information

**Power Control :** Controls , Schedule, Ping, M2M mode, Rotation mode

**Network :** Setting

**Application :** Email , DDNS, Communication & IP Service


**System :** Management, Information, SysLog & Firmware

**Logout**

## 4.1 Top Column

### 4.1.1 Device name


This section show the device name . You can change the device name here : Application → IP Service → Device name Change name “ IP POWER 9850XX “ as “Enjoy 9850XX “



The screenshot displays the IPPOWER web interface. On the left, a sidebar menu is visible with categories: Power Control (Control, Schedule, Ping, M2M mode, Rotation System), Network (Setting), and Application (Email, DDNS, Communication, IP Service). The 'IP Service' option is highlighted with a red box. The main content area shows the 'IP Service Setting (Search)' form. The 'Device Name' field is highlighted with a red box and contains the text 'IPPOWER'. The 'Apply' button is also highlighted with a red box. Below the form, there is a section for 'CNT(MQTT) Setting (Remote control)' with an 'Apply' button.

**Notice : Please do not use symbol like !@#\$%^&\*()\_+ as the character of the device name .**

After apply the change , please click “ Refresh “ of the webpage to get the display update .






### 4.1.2 Column Display :

For tablet user to control 9850XX easily , user can select to show or to hide the left control section by pressing the blue area near device name for Smartphone control :

- With left control section :



- Without left control section:




### 4.1.3 Time

In this section, it shows Time at Year – Month – Date Hours : Minutes : Seconds .



To setup the Time , Please go to “ System → Management → NTP Settings “ , please press “Apply” to save the new setting . There are 3 time sync situation:

Time - Manual setting , Current time - sync with Local PC or NTP Server



The screenshot shows the 'System Management' web interface. The left sidebar has a menu with 'Management' highlighted. The main content area is titled 'System Management' and contains several settings sections: Administrator Settings, Language Settings, Web Server Settings, and NTP Settings. The NTP Settings section is highlighted with a red box and contains the following fields:

NTP Settings	
Date	07 / 28 / 2022 (MM/DD/YY)
Time	17 : 23 : 53 (HH:MM:SS) <input type="button" value="Apply"/>
Current Time	Thu Jul 28 17:23:52 GMT 2022 <input type="button" value="Sync with local time"/>
Time Zone	(GMT+0800)ChinaCoast HongKong
NTP Server	pool.ntp.org ex: time.nist.gov
Sync with NTP	Every 1 hours <input type="button" value="Apply"/>

1. Time - Manual setting : fill the assigned time and then click “Apply “ in time section
2. Current time - sync with the local PC log into 9850XX .
3. NTP Server - sync with the assigned sever and can setup the times for sync

Notice: As using NTP server, as webpage time count will be slower than the device time, please refresh the webpage or use the telnet command “ to confirm the device time.

```
IP_POWER login: admin
Password:


BusyBox v1.12.1 (2019-07-08 01:01:56 PDT) built-in shell (ash)
Enter 'ioctrl -h' for a list of built-in commands.

# date
Mon Oct 7 13:54:37 GMT 2019
#
```

## 4.2 Power Control

The IO Control Section allows you to directly / automatically control the outlets of the 9850XX as well as schedule Daily, Weekly, and Monthly power cycles.

There are 5 sections: Control, Schedule, Ping, M2M mode, Rotation System



### 4.2.1 Control

There are 2 setting pages in this Section. One is "Power Control" and another one is "Advance Setup"

#### A. Power Control :



User can do the following 3 basic operation in this page :


1. Manually Control : Each port ON or OFF directly by pressing the button.

For example : The following pictures means that Power #1 & #4 is ON , Power #2 & #3 is OFF





2 Power Cycle : Manually Control the relay delay some times to turn ON or OFF .

The relay cycle time can be set from 1 to 9999 seconds







- As ON, Select OFF and press “Power cycle ” then the outlet status is ON → OFF.
- As ON, Select ON and press “Power cycle ” then the outlet status is ON → OFF → ON.
- As OFF, Select ON and press “Power cycle ” then the outlet status is OFF → ON.
- As OFF, Select OFF and press “Power cycle ” then the outlet status is OFF → ON → OFF


User can setup the time and the final status in power cycle as ON / OFF



**For example :** ( sec = seconds )

	<p>Original Outlet as “ ON “ , select final status as “ OFF “ &amp; fill 3 sec . After press “ power cycle “ button, the outlet will be ON for 3 seconds and then turn OFF .</p> <p style="text-align: center;">ON ( 3 sec ) → OFF</p>
	<p>Original Outlet as “ OFF “ , select final status as “ OFF “ &amp; fill 15 sec . After press “ power cycle “ button, the outlet will turn ON for 8 seconds and then turn OFF .</p> <p style="text-align: center;">OFF → ON ( 15 sec ) → OFF</p>
	<p>Original Outlet as “ OFF “ , select final status as “ ON “ &amp; fill 15sec . After press “ power cycle “ button, the outlet will turn OFF for 15 seconds and then turn ON .</p> <p style="text-align: center;">OFF ( 15 sec ) → ON</p>
	<p>Original Outlet as “ ON “ , select final status as “ ON “ &amp; fill 10sec . After press “ power cycle “ button, the outlet will turn OFF for 10 seconds and then turn ON .</p> <p style="text-align: center;">ON --&gt; OFF ( 10 sec ) → ON</p>

3 Group Setting : User can control more than one outlet by press the right side “Apply “ button . For safety concern , each port of 9850XX will turn ON or OFF one after one .



- Apply : Setup the ON/OFF by the buttons status .
- Inverter : Change the outlet status from ON to OFF ,or form OFF to ON by one button control.

## B. Advance Setup :

In this page, user can setup Name of each port , Notification , Power interval, WOL&SOL Trigger Relay, Shutdown On LAN Settings , Wake On Lan Settings

Power Control

Port Name Setting				
Outlet1	Outlet2	Outlet3	Outlet4	
Jason	Tony	power3	power4	

Notification Setting				
Name	Jason	Tony	power3	power4
Forbidden off manually	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Forbidden Power cycle	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Email Alerts	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Beep Alert	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Power Cycle Time	00 Seconds	00 Seconds	00 Seconds	00 Seconds
Default Power Delay Enable	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	11 Seconds	12 Seconds	13 Seconds	14 Seconds
Default Power Status	LAST	LAST	LAST	LAST
Apply				

Power interval	
Enable	Interval time(1~5sec)
<input type="checkbox"/>	1 Sec
Apply	

WOL & SOL trigger Relay	
OFF	Apply

Shutdown On Lan Settings	
Name	Delay Time
Jason	00 Seconds
Tony	00 Seconds
power3	00 Seconds
power4	00 Seconds
Apply	

Wake On Lan Settings	
Control Outlet	MAC
Jason	000000000000 <input type="button" value="Send"/>
Tony	000000000000 <input type="button" value="Send"/>
power3	000000000000 <input type="button" value="Send"/>
power4	000000000000 <input type="button" value="Send"/>
Apply	

### B.1 Name of each port

User can name each power by click the name above the power button . The number of character is max. 12 characters and Please change the name in English only and do not use symbol like !@#%&\*()\*\_+

**Note :** Please change the name in English only and do not use symbol like !@#%&\*()\*\_+

Example : Change the outlet #1 from “ power1 “ to “ sever-001 “

Port Name Setting			
Outlet1	Outlet2	Outlet3	Outlet4
server-001	power2	power3	power4

WER 985


Please enter Power1 name:

VIOSYS


Port Name Setting			
Outlet1	Outlet2	Outlet3	Outlet4
power1	power2	power3	power4

After click confirm , the page will go to “ power control “ page to show the update name.




## B.2 Notification setting

User can do several notification here .



- Forbidden off manually : Select by port will disable the power control in webpage . The disable is for the control in webpage only .The control through HTTP command is still working .

For Example : Select the control in webpage of power 1 & power4 for be disable



Then the page will be as following :



- Forbidden power cycle: Select by port will disable the power cycle control in webpage. The disable is for the control in webpage only .The control through HTTP command is still working.

For Example : Select the power cycle control in webpage of power 1 & power 2 for be disable

Notification Setting				
Name	power1	power2	power3	power4
Forbidden off manually	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Forbidden Power cycle	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Advance Setup



power1

60  
Sec
Power Cycle
⏏
ON
▼



power2

60  
Sec
Power Cycle
⏏
ON
▼



power3

60  
Sec
Power Cycle
⏏
ON
▼



power4

60  
Sec
Power Cycle
⏏
ON
▼

- Email Alerts :

User can enable /disable the e-mail alarm here .The e-mail alarm section allows 9850XX to notify user by following situation :

- Receive E-mail with IP information & MAC Address as 9850XX device boot up.
- Receive E-mail as ON/OFF status change in each output .

To get E-mail about of power status , please go to “ Application → E-mail.

Notification Setting				
Name	power1	power2	power3	power4
Forbidden off manually	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Forbidden Power cycle	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Email Alerts	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>

- Beep Alarm Setting:

User can setup the operation beep ( short time beep) sound here.

Notification Setting				
Name	power1	power2	power3	power4
Forbidden off manually	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Forbidden Power cycle	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Email Alerts	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Beep Alert	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>



- **Default Power Status :** The control section allow user to set the power status on ON or OFF or LAST when the device get power rebooted . As select “Last “ , the output will be at the same status ON / OFF before the device power turn off . To save the setting here , please click “Apply “ button .

Notification Setting				
Name	power1	power2	power3	power4
Forbidden off manually	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Forbidden Power cycle	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Email Alerts	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Beep Alert	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Default Power Status	<div style="border: 2px solid red; padding: 2px;">           LAST ▾            OFF            ON            LAST         </div>	LAST ▾	LAST ▾	LAST ▾

**B.3 Power Interval:** It's the delay function which works on the ON/Off buttons for the manual control at the interface of the webpage. User can delay the action time as press the control button in webpage.

Power interval	
Enable	Interval time(1~5sec)
<input type="checkbox"/>	3 Sec

**B.4 WOL&SOL:** Trigger Relay: When you enable the WOL function, turn the Trigger Relay on will connect the WOL and SOL function.

WOL & SOL trigger Relay	
OFF ▾	<input type="button" value="Apply"/>

**B.5 Shutdown On Lan Settings :**

Shutdown On Lan Settings				
Name	power1	power2	power3	power4
Delay Time	60 Seconds	60 Seconds	60 Seconds	60 Seconds

9850XX can be used to safely turn off the **WINDOWS or LINUX** system through Network. With this feature you can remotely shutdown any system which that is connected to the IP Power 9850XX through normal Windows / LINUX shut down procedure. Before operating the software shutdown function it is essential to install our software.

If you are requiring to use this function, please contact with the seller, and will provide the file to install.  
File name: Shutdown\_On\_LAN

**NOTE :** The delay time setup in this section is for “ Shutdown ON LAN “ procedure . Not for outlet ON/OFF function

## B.6 Wake on Lan settings :

This is a application for PC / Server / Main board which had been enable the “ WAKE ON LAN “ function in own setting . User need to know the MAC address of the PC /Server to do the wake up on LAN function .

Wake On Lan Settings		
Control Outlet	MAC	
power1	<input type="text" value="000000000000"/>	<input type="button" value="Send"/>
power2	<input type="text" value="000000000000"/>	<input type="button" value="Send"/>
power3	<input type="text" value="000000000000"/>	<input type="button" value="Send"/>
power4	<input type="text" value="000000000000"/>	<input type="button" value="Send"/>

1  Duration Mode  Once  Every Week  Every Day

Date: From  to

Time  :  :  (Hr:Min:Sec)

Schedule power action  Schedule Power Rotation

<b>Jason</b> <input checked="" type="checkbox"/> <input type="text" value="OFF"/>	<b>Tony</b> <input checked="" type="checkbox"/> <input type="text" value="OFF"/>	<b>power3</b> <input checked="" type="checkbox"/> <input type="text" value="OFF"/>	<b>power4</b> <input checked="" type="checkbox"/> <input type="text" value="OFF"/>
--	---	---	---

**Global Ping Base Setting**

Ping Interval  Sec. Response Time Out  ms.

Ping After Action Delay  Sec. Action Max repeat times  (0=non stop)

Conditional Mode  Single  OR  And

IP & Host Name	Check	Failed times then action	Repeat
<input type="text" value="www.baidu.com"/>	<input type="button" value="Check"/>	<input type="text" value="03"/>	<input type="text" value="Stop"/>
<input type="text" value="www.google.com"/>	<input type="button" value="Check"/>	<input type="text" value="03"/>	
<input type="text" value="www.yahoo.com"/>	<input type="button" value="Check"/>	<input type="text" value="03"/>	
<input type="text" value="www.sony.com"/>	<input type="button" value="Check"/>	<input type="text" value="03"/>	

Ping failure action



<b>Jason</b> <input checked="" type="checkbox"/> <input type="text" value="ON"/>	<b>Tony</b> <input checked="" type="checkbox"/> <input type="text" value="OFF"/>	<b>power3</b> <input checked="" type="checkbox"/> <input type="text" value="OFF"/>	<b>power4</b> <input checked="" type="checkbox"/> <input type="text" value="OFF"/>
---	---	---	---

WOL=Wake-On-Lan, SOL=Shutdown-On-Lan

## 4.2.2 Schedule

In this section , user can see the setting schedule list first up to 29 rules . To setup each schedule , please press “ Schedule Setting “ , then user can get the “ Schedule List “ page as following :

Please click the button to switch between “ Schedule Setting “ & “ Schedule list “ :



The schedule allows you to control the power outlet or turn ON / OFF/ RESET at assigned time


- Adding a Scheduled Event

1. Select the Action Duration :


There are 3 setting - Once , Every Day . Every Week

2. Select a Specific Date Range where the device will repeat the desired actions during the time specified.


3. Select the Time Period.
4. Choose the Action : Enable power # by clicking in the small square to mark “ v “ , and select one from the power action of OFF/ON/RESET as you need.



Once the scheduler has been Set Up , hit the “ ADD No.:X Power Schedule “ button and you will see your setting located on the button of the Action section .



- **Apply / Edit a Schedule Event :**



Please select the Rule you want to edit in Scheduler Table. , Change the setting like Duration , Date , Time and Action. Then Press “Apply Np. X Sch “ button to confirm the setting and you will see the page refresh and new setting display in Scheduler list

- **Delete** - Click “ Delete “ button to remove a rule from the list .

### Rotation Start/Stop:

In the function of the Power Rotation. User can setup a certain time to do this Power Rotation. User can set up a time to start the rotation but need to set another time to stop the rotation

### Rotation Start :

Schedule List

1 Duration Mode  Once  Every Week  Every Day

Weekly select:

Sunday  Monday  Tuesday  Wednesday  Thursday  Friday  Saturday

Date: From 2022/06/01 to 2022/07/04

Time 17 : 18 : 17 (Hr:Min:Sec)

Schedule power action  Schedule Power Roation **Roation-Start**

ON Period 1 min

Interval 1 min

Repeat the mutichannel powe cycling in order during the specified period

### Rotation Stop:

Date: From 2022/06/01 to 2022/07/04

Time 17 : 18 : 17 (Hr:Min:Sec)

Schedule power action  Schedule Power Roation **Roation-Stop**

### 4.2.3 Ping


The Ping function allows the device to Ping an IP Address automatically to act as a watchdog to make sure the device getting Ping and working properly. Please Click the button to switch between “ Ping Setting “ & “ Ping List “ . User can hide the setting section by press “ Ping List “

**There are 4 rules for Ping only, each rule can setup 1~4 outlets.**

- **Ping List Page :**




- **Ping Setting Page :**



There are 3 sections of the setting area :

1. **Setting Rule Numbers :**

User can click to select different rules numbers at the right side button “ Rule No: X “ as following pictures .



2. Ping Base Setting :

Global Ping Base Setting			
Ping Interval	5 Sec.	Response Time Out	900 ms.
Ping After Action Delay	5 Sec.	Action Max repeat times	1 (0=non stop)

- Ping Interval : The number of seconds ( Sec. ) between each ping .
- Respond Time Out : The number of milliseconds (= ms.) of the device will wait for a response from the Pinged device if no ping is detected within this time it will be considered a Ping failure.
- Ping After Action Delay : After ping finished , do the action after setting seconds ( Sec. )
- Action Max. repeat times : Set the times to execute the Ping Failure action  
Set 0 means action non stop - Keep action & no limit times.

As setting finished , please click “ Apply “ to save the setting in this area , the webpage will refresh and user can see the final setting result. Ten different set up rules for different port .

3. Other Setting :

The setting here is for each rule.

Conditional Mode			
<input type="radio"/> Single <input type="radio"/> OR <input checked="" type="radio"/> And			
IP & Host Name	Failed times then action	Repeat	Rule No1
www.yahoo.com <input type="button" value="Check"/>	00	Stop	
www.google.com <input type="button" value="Check"/>	00	Stop	
Ping failure action <input type="checkbox"/>			
<input type="button" value="Apply Rule"/>		<input type="button" value="Delete"/>	

● Logic Mode :

User can select the action activate by one / two IP Host failure or either one fail

- Single : Execute Action by one IP Host failure .
- OR : Execute Action by either one IP Host failure as setting 2 pcs IP Host
- And : Execute Action by both IP Host failure as setting 2 pcs IP Host

**Single :** 9850XX will Ping one IP address. As the IP fail times reach to the setting times . Action (ON/OFF/RESET) will be activated .

Conditional Mode			
<input checked="" type="radio"/> Single <input type="radio"/> OR <input type="radio"/> And			
IP & Host Name	Failed times then action	Repeat	Rule No1
www.google.com <input type="button" value="Check"/>	03	Stop	
		Continue	
Ping failure action <input type="checkbox"/>			
<input type="button" value="Apply Rule"/>		<input type="button" value="Delete"/>	

**Ping 1**

WOL=Wake-On-Lan, SOL=Shutdown-On-Lan

```

graph LR
    Start[No.1 Ping every 5sec] --> Baidu[www.baidu.com]
    Start --> Sony[www.sony.com]
    Baidu --> BaiduTO[0.9sec Timeout Ping 3 times]
    Sony --> SonyTO[0.9sec Timeout Ping 3 times]
    BaiduTO --> EitherFail[Either Fail]
    SonyTO --> EitherFail
    EitherFail --> Seq[1 2 3 4]
    Seq --> Repeat[Repeat 1Times after 5sec]
  
```

**OR** : 9850XX will Ping 2 IP address. Either one IP fail times reach to the setting times.  
Action (ON/OFF/RESET) will be activated .

**AND** : 9850XX will Ping 2 IP address. Both IP fail reach to the setting times.  
Action (ON/OFF/RESET) will be activated.


- IP & Host Name : Input the IP Address ( ex: 122.116.123.138) or Host - web address ( ex: www.google.com) user would like to Ping.  
User can use the “ **ping test** “ button to check the address valid or not
- Failed times then action : Setup the ping failure times for 9850XX to execute the setup ON/OFF / Reset action of setting .
- Repeat : After the ON/OFF/Reset action , user can setup the Ping action to keep ping ( Continue ) or to Stop Ping ( Stop ) .
- Enable Ping function : In the selected Rules number , please select the outlet number power to activate as ping fails and then press “ Apply Rule Action “ button to confirm the setting .
- Ping failure action :  
When the number of Ping Failures times have been reached. The device can be set to “ ON , OFF or Reset “ function

Reset: Can set up the time gap from OFF to ON. The “ Sec “ section is for action as Reset only.

- ON
  - OFF
  - Cycle: It means outlets turn OFF to ON
  - WOL: Wake On Lan
  - SOL: Shutdown On Lan
  - Relink: It means to reconnect the network. If the setting is DHCP, 9850XX may get a new IP address as reconnect to the router.
- > P.S: If the network connection is not stable or change it's IP on internet frequently, we suggest to enable this function to Ping the 4G router. 9850XX will relink the network as there is no ping reply from the network.

The setting times range is 1 to 999 sec.





Select the number of Ping Failures that user prefer to do before the action is activated.

EX: Result of setting

#### 4.2.4 M2M mode

- This is a function to control another 9850XX automatically. There are two directions : Control in LAN or Control through Internet – MQTT

##### 1.M2M- Local ( LAN ):

In this function , device B is a SLAVE device . User need to select enable , filled the IP address and login information of the HOST / Master device.

M2M(LAN) Setting	
Enable	<input type="checkbox"/>
Host	<input type="text"/>
Port	<input type="text" value="80"/>
User	<input type="text" value="admin"/>
Password	<input type="password" value="....."/>

- For example :  
One 9850XX name device A ( IP : 10.33.122.50 ) , another 9850XX name device B ( 10.33.122.28 ) .
  - In the webpage of device B , we enable the function , set up the IP and the login username and password of device A ( as HOST ) .
  - As we setup the outlet # 1 of device A as ON , then the outlet #1 of device B will turn ON.
  - As we setup the outlet # 2 of device A as OFF , then the outlet #2 of device B will turn OFF too.
- Before you setting M2M. please open two device webpage and enable the setting at the same time, if you only setting device A to enable M2M, device B won't follow device A action until both device have set M2M enable.

Notice : User can set device A to control B and also device B to control A , then the two devices will be auto control of each other .

##### 2.M2M-MQTT ( Internet ) :

- To use this function , user need to enable the CNT( MQTT ) function ( register to Aviosys MQTT HOST ). In this function , device B is a MASTER device . User need to select enable, filled the MAC address and login information of the SLAVE device .

The screenshot shows the 'M2M(LAN) Setting' interface. At the top right, there is a yellow button labeled 'MQTT'. A red arrow points from this button to the main settings area. The settings area includes a table with the following fields:

Enable	<input type="checkbox"/>
Host	<input type="text"/>
Port	80
User	admin
Password	*****

Below the table is an 'Apply' button.



M2M machine outputs are corresponding to another machine outputs

**Local**

**M2M(Internet) Setting**

MQTT M2M Enable

**Controlled Device Setting**

MAC	User	Password	
<input type="text" value="007623000310"/>	<input type="text" value="admin"/>	<input type="text" value="*****"/>	<input type="button" value="Test"/>

**Apply**

- Before setting the MQTT, click the the IP service in Application, and you will see the “ CNT(MQTT ) Setting (Remote control) ”, follow the red button to click the enable function, then choose the IPPower option in MQTT Service. After the setting, click the apply and the MQTT function will be enable.

Notice: All the IP device want to connect each other through MQTT must get this procedure.

The screenshot shows two parts of the configuration interface. On the left is a sidebar menu with categories: Power Control, Network, and Application. Under Application, 'IP Service' is highlighted with a red box. The main area shows the 'IP Service Setting (Search)' form with fields for Enable, IP Service Server, Device Name, Country, City, and myipedit login Account. Below this is a link: 'Find IPPOWER 9858 device on myipedit.com'. The second part shows the 'CNT(MQTT) Setting (Remote control)' form with a dropdown menu for 'MQTT Service' set to 'IPPower', an 'Enable' checkbox, and a 'Status' field. A red arrow points to the 'Enable' checkbox.

- Setting the MQTT:

M2M machine outputs are corresponding to another machine outputs

*Local*

**M2M(Internet) Setting**

MQTT M2M Enable

**Controlled Device Setting**

MAC	User	Password	
<input type="text" value="007623000310"/>	<input type="text" value="admin"/>	<input type="password" value="....."/>	<input type="button" value="Test"/>

- Click the button in MQTT M2M Enable.
- In Controlled Device Setting, type the Device MAC you want to connect with. We recommend not to change the user and password in the first, then click apply, the other device connect the device you are setting.
- For example : one 9850XX name device A ( MAC : 007623000310 ) , another 9850XX name device B ( MAC : 007650002DF8, IP - 10.33.122.28 )
  - In the webpage of device B , we enable the function , set up the IP and the login username and password of device A ( as SLAVE ) .
  - As we setup the outlet # 1 of device B as ON , then the outlet #1 of device A will turn ON too
  - As we setup the outlet # 2 of device B as OFF , then the outlet #2 of device A will turn OFF too

Notice : 1. User can set device A to control B and also device B to control A , then the two devices will be auto control of each other .

#### 4.2.5 Rotation system

- It is a inquire function by specific application, for those who want to test with their system, and need such function to check their device status.

Multi-rail power rotation mode.

**Rotation System Settings**

Enable	<input type="checkbox"/>
ON Period	<input type="text" value="1"/> min
Interval	<input type="text" value="1"/> min

- Enable : Enable the rotation function
- On Period minute ( from 1 up to 999999999999 minutes )
- Interval: minute ( from 1 up to 999999999999 minutes )

As user set : enable , on period as 1 min and interval as 2 min ,

The 4 outlets will work automatically as following sequence:


The Outlet #1 turn ON for 1 min only and then turn off for 2 min , then the Outlet #2 turn ON for 1 min only and then turn off for 2 min , then the Outlet #3 turn ON for 1 min only and then turn off for 2 min , then the Outlet #4 turn ON for 1 min only and then turn off for 2 min , then back to outlet 1 ( the first line action ) . The above action sequence will keep rotation at outlet 1 2 3 4.

## 4.3 Network

There are 3 sections in this port: LAN Network, DNS setting and Port setting

LAN Network Settings :

The network status is connected by ether cable with RJ45 connector. There are 2 network connection way : Static IP / DHCP




### A. STATIC (fixed IP)

Setup IP address , DNS and Port manually. This allows the 9850XX to obtain an IP Address automatically from user`s server connected to Internet. Recommended for users who need to control through Internet.

**Please do fill up the correct gateway / port for login from Internet .**

**Please do fill up the correct DNS server for sending / receiving email ( alarm) .**



The screenshot shows the network configuration interface. At the top right, "LAN IP Select" is set to "Static Mode(fixed IP)". A red arrow points to this dropdown menu. Below this, there are three sections:

- Setup LAN Static IP**

IP Address	192.168.1.168
Subnet Mask	255.255.255.0
Default Gateway	192.168.1.1
- Secondary IP  Enable  Disable
- Setup Static DNS**


Primary DNS Server	168.95.1.1
Secondary DNS Server	8.8.8.8
- Port Setting**

Port(80~65535)	80
WAN IP Address	0.0.0.0
Port Assigned	80

At the bottom, there are "Apply" and "Cancel" buttons.

## Secondary IP:

This function like a “ backdoor ”. If the user forget the IP address, they can log in through this IP as it enable.



Secondary IP  Enable  Disable

Get DNS from DHCP Server

Primary DNS Server	168.95.1.1
Secondary DNS Server	8.8.8.8

Port Setting

Port(80~65535)	80
WAN IP Address	0.0.0.0
Port Assigned	80

Apply

## B. DHCP Mode


Obtain IP address via DHCP mode . setup the DNS and port

This allows the 9850XX to obtain an IP Address automatically from user`s server connected to Internet. Recommended for non- advance users. User can only revise the Host Name under DHCP mode. This is also the default setting for fast LAN connection solution.

As the IP from DHCP Service of user`s router will be changed by router . 9850XX will remember last IP of 9850XX assigned by user`s router in “Last DHCP state “ for information.

**Please do fill up the correct gateway / port for login from Internet .**

**Please do fill up the correct DNS server for sending / receiving email (alarm) .**



LAN IP Select **DHCP (Auto Config)**

Get LAN IP from DHCP

IP Address	192.168.100.137
Subnet Mask	255.255.255.0
Default Gateway	192.168.100.1

Secondary IP  Enable  Disable

Get DNS from DHCP Server

Primary DNS Server	127.0.0.1
Secondary DNS Server	168.95.1.1


Port Setting

Port(80~65535)	80
WAN IP Address	0.0.0.0
Port Assigned	80

Apply Cancel

### C. PPTP

Enable your PPTP first, and setting your IP address, User name password, then click the apply to activate the PPTP mode



The screenshot shows the 'PPTP Mode' configuration page. At the top right, 'VPN Type select' is set to 'PPTP'. The main configuration area is a table with the following fields:


PPTP Mode	
PPTP	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Pptp Server IP Address	pptp_server
User Name	pptp_user
Password	.....
VPN IP Address	0.0.0.0

Below the table is an 'Apply' button. A red box highlights the 'Enable/Disable' radio buttons and the 'User Name' and 'Password' fields.

### D. UPNP

With UPNP function, user can log in webpage through Internet without setting Port forwarding / port mapping in your router. No matter use "FIX IP" or "DHCP", user can enable this UPNP function.

Notice : It support to pass through one router and may not work as 9850XX under multiple routers.



The screenshot shows two configuration pages. The top page is 'Port Setting' with 'LAN IP Select' set to 'UPNP'. The fields are:

Port Setting	
Port(80~65535)	80
WAN IP Address	0.0.0.0
Port Assigned	80

Buttons: 'Apply', 'Cancel'. A red arrow points to the 'LAN IP Select' dropdown.

The bottom page is 'UPNP' with the following fields:


Enable	<input type="checkbox"/>
Port	44615 (81~65535)

Button: 'Apply'

**Please do fill up the correct gateway / port for login from Internet .**


**Please do fill up the correct DNS server for sending / receiving email ( alarm ) .**

## 4.4 Application Settings



### 4.4.1 Email

There are 2 sections in this part -- E-mail setting and POP3 Control :



The screenshot shows the "E-mail Setting" configuration page. It includes a table for SMTP server settings and a checkbox for POP3 Control.

SMTP Server :	Gmail <input type="text" value="smtp.gmail.com"/>
Port :	587 <input checked="" type="checkbox"/> StartTLS
User :	aviosys102@gmail.com
Password :	.....
From :	aviosys100@gmail.com
To :	aviosys101@gmail.com
To1:	aviosys103@gmail.com
To2:	aviosys104@gmail.com

Buttons: Email Test, Apply

POP3 Control  Enable

#### ● Email Setting :

User can get e-mail advice as one of the following situation happen :

- Receive E-mail with IP information & MAC Address as 9850XX device boot up.
- Receive E-mail as ON/OFF status change in each output .

**Notice : To send out the e-mail successfully , please double check the setting of user DNS .  
(Network → DNS setting)**

The 9850XX allows user to send from public e-mail account , such as @gmail or @hotmail or @yahoo.com

- **SMTP Server:** This is the mail server of sender .

If user select @gmail or @hotmail account as SMTP Server , 9850XX will fill the SSL & Port automatically

- **Port** : This is the port of SMTP Server. Most common port to send out e-mail is port 25
- **Start TLS** : It depends on the inquire of the email server to enable or disable this inquire .

As use Gmail account , please enable this function .

- **User** : Login for the e-mail address . Ex: [9850XX@gmail.com](mailto:9850XX@gmail.com)
- **Password**: Password for the e-mail address. EX : 12345678
- **From** : Mail sender address to send the E-Mail out . Ex.: [9850XX@gmail.com](mailto:9850XX@gmail.com)
- **To** : Mail receiver address to get the E-Mail in Ex.: 9223@hotmail.com

- **E-mail test** : Can help to check if the e-mail setting works.

- **Apply** : To store the setting in this section .

For example :

1. Get Email alarm as outlet changed :

Port Name Setting				
Outlet1	Outlet2	Outlet3	Outlet4	
power1	power2	power3	power4	

Notification Setting				
Name	power1	power2	power3	power4
Forbidden off manually	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Forbidden Power cycle	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Email Alerts	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Beep Alert	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Power Cycle Time	60 Seconds	60 Seconds	60 Seconds	60 Seconds
Default Power Delay Enable	11 Seconds	12 Seconds	13 Seconds	14 Seconds
Default Power Status	ON	ON	OFF	OFF

## ● POP3 Control

User can control each port turn ON or turn OFF by e-mail. The command format is limited .

Please enable the function first.

POP3 Control  Enable

POP3 Server : Gmail pop.gmail.com

From : aviosys@gmail.com

Port : 110

User : aviosys1

Password : .....

Tag : Test

Interval(Minute) : 2

Mail Number : 100

CTRL Format :  Subject  Body

Example:  
**E-Mail Test:**  
 yourmail  
**Subject:**  
 IPPOWERCTRL:TAG=Test;POWER1=OFF;POWER2=OFF;POWER3=OFF;POWER4=OFF  
**Body:**



## Settings Section :

To set up 9850XX be controlled by e-mail , user need to know the both **sender`s e-mail address and receiver`s e-mail account Name and Password.**

- **POP3 Server:** This is receiver's mail server
- **From :** Sender's email address . Ex.: aviosys@gmail.com
- **Port :** This is the port of POP3 Server.

If user select @gmail or @hotmail account as SMTP Server , 9850XX will fill the SSL & Port automatically.

- **User :** Username to login the receiver's e-mail Ex.: aviosys1 or aviosys1@gmail.com
- **Password:** Password for the e-mail address. EX. : 12345678
- **Tag :** User can use any message for 9850XX to recognize this mail as 9850XX command mail .

EX.:

As type " Test " in TAG area, the command contents is as following:

```
IPPOWERCTRL:TAG=Test;POWER1=OFF;POWER2=OFF;POWER3=OFF;POWER4=OFF
```

- **Interval ( minutes ) :** The period of time between Send and Receive the command e-mail.
- **Mail Number :** For 9850XX to search as command mail in the number of your email receiver latest . EX. : setup 20 that 9850XX will check the latest 20pcs email in receivers mail box for the 9850XX command mail
- **CTRL format :** Control format by subject or by body ( e-mail contents)

For example : Use Gmail as sender and receiver

- Sender`s e-mail : 123@gmail.com
- Username to log in sender`s @gmail : [123@gmail.com](mailto:123@gmail.com) or [abc@def.com](mailto:abc@def.com)
- Password to log in sender`s @gmail : 12345678

**Command format & Example :**


User can get the e-mail command contents in the section . And execute an e-mail as press “Submit “ if user has e-mail setting in the PC as following :

CTRL Format :  Subject  Body

Apply

**Example:**  
**E-Mail Test:**  
yourmail  
**Subject:**  
IPPOWERCTRL:TAG=Test;POWER1=OFF;POWER2=OFF;POWER3=OFF;POWER4=OFF  
**Body:**

Submit



Command format :

**IPPOWERCTRL:TAG=Test;POWER1=OFF;POWER2=OFF;POWER3=OFF;POWER4=OFF**

There are 2 section of the command

1. **IPPOWERCTRL:TAG=Test**

This is command part. Beside the tag message part ( like Test on above example) user can change in setting section , the other command must be **CAPITAL** and are fixed content .

2.  **;POWER1=OFF;POWER2=OFF;POWER3=OFF;POWER4=OFF**

This is to set the outlet number ( POWER1= ) and action ( ON/OFF) , user can only control 1~4 port ON/OFF by e-mail. Do each outlet command

EX.: Put “ 14ON” in tag section and place the command as following : ( at subject or body depends one user’s setting) :

IPPOWERCTRL:TAG=14ON;POWER1=OFF;POWER4=ON

**E-mail example :**

- Execute e-mail command by “ Subject “

The screenshot shows a web interface for configuring an email command. At the top, there is a 'CTRL Format :' label. Below it, there are two radio buttons: 'Subject' (which is selected and highlighted with a red box) and 'Body'. An 'Apply' button is located to the right of these radio buttons. Below the radio buttons, there is an 'Example:' section. Under 'Example:', there is an 'E-Mail Test:' label and a text input field containing 'yourmail'. Below that, there is a 'Subject:' label and a text input field containing the command: 'IPPOWERCTRL:TAG=Test;POWER1=OFF;POWER2=OFF;POWER3=OFF;POWER4=OFF'. This text input field is also highlighted with a red box. Below the 'Subject:' field, there is a 'Body:' label and an empty text input field.

- Execute e-mail command by “ Body “

The screenshot shows a web interface for configuring an email command. At the top, there is a 'CTRL Format :' label. Below it, there are two radio buttons: 'Subject' and 'Body' (which is selected and highlighted with a red box). An 'Apply' button is located to the right of these radio buttons. Below the radio buttons, there is an 'Example:' section. Under 'Example:', there is an 'E-Mail Test:' label and a text input field containing 'yourmail'. Below that, there is a 'Subject:' label and an empty text input field. Below the 'Subject:' field, there is a 'Body:' label and a text input field containing the command: 'IPPOWERCTRL:TAG=Test;POWER1=OFF;POWER2=OFF;POWER3=OFF;POWER4=OFF'. This text input field is also highlighted with a red box. At the bottom of the interface, there is a 'Submit' button.

## 4.4.2 DDNS

The DDNS section allows user to setup the 9850XX with a DDNS server (i.e. [www.dyndns.com](http://www.dyndns.com)). After the server has been setup correctly, enter the necessary information into the 9850XX DDNS settings.

**Note:** The DNS server will have extra change as apply new account.

DDNS Setting	
Enable	<input type="checkbox"/>
Service Provider :	None
Account :	
Password :	
Domain Name :	

Apply Cancel

Account : the Username / account name of DDNS account

Password: the Password of DDNS account

Domain name: The DDNS name user apply. Ex.: abc.dyndns.org

## 4.4.3 Communication

9850XX supports SNMP, Telnet , Modbus TCP and BACnet TCP

SNMP:	
Enable	<input type="checkbox"/>
SNMP version:	1.2c
Community Authority :	NA
Community Name :	private
Trap type :	NA
Host(192.168.1.1:162) :	192.168.1.1:162
Trap Community :	private
MIB file	IPPOWER-MIB.txt

Apply

TELNET:	
Enable	<input checked="" type="checkbox"/>
SSH	<input checked="" type="checkbox"/>
SSH-KEY	Renew

Apply

TCP Modbus	
Modbus Enable	<input type="checkbox"/>
Port	502

Apply

BACnet	
Enable	<input type="checkbox"/>
Port	47208

Apply

## A.SNMP

This section is for development of system integrator who is familiar with SNMP knowledge. In community Authority , user can select “ Read only” or “Read / Write”

### Communication Setting:

SNMP:	
Enable	<input type="checkbox"/>
SNMP version:	1,2c ▾
Community Authority :	N/A ▾
Community Name :	N/A <input type="text"/>
Trap type :	<div style="border: 1px solid black; padding: 2px;">N/A Read Only Read/Write</div>
Host(192.168.1.1:162) :	192.168.1.1:162
Trap Community :	private
MIB file	<a href="#">IPPOWER-MIB.txt</a>
<input type="button" value="Apply"/>	

In “ Trap “ type ,user can select “ v1 trap “ , “ v2c trap “ or “ v2c inform”

### Communication Setting:

SNMP:	
Enable	<input type="checkbox"/>
SNMP version:	1,2c ▾
Community Authority :	N/A ▾
Community Name :	private <input type="text"/>
Trap type :	N/A ▾
Host(192.168.1.1:162) :	<div style="border: 1px solid black; padding: 2px;">N/A v1 trap v2c trap v2c inform</div>
Trap Community :	<input type="text"/>
MIB file	<a href="#">IPPOWER-MIB.txt</a>
<input type="button" value="Apply"/>	

In MIB file section, user can get MIB information.

## B. Telnet

In This section is for development of system integrator who is familiar with Telnet to enable /disable the

TELNET:	
Enable	<input checked="" type="checkbox"/>
<input type="button" value="Apply"/>	

Please enable the telnet function in “Application “ → “ Communication “

```
C:\> Telnet 192.168.1.18

IP login: admin
Password:
```

```
C:\> Telnet 192.168.1.18

#
# ioctrl -h
**-----**
Usage: ioctrl
[-h ! --help l.....: display this help
[-s ! --setpower p6=0011 or p6x=1(x=1,2,3,4)l.....: turn on/off ports on the d
evice
[-p ! --getpower l...: get the on/off status of the device
[-c ! --current l.....: get the current value of the device
[-t ! --temp l.....: get the temperature value of the device
[-v ! --version l.....: display version information
-----
# ioctrl -s p6=1111
p61 ok,p62 ok,p63 ok,p64 ok,
# ioctrl -c
Current value: 0.000000, 0.000000, 0.000000, 0.000000
# ioctrl -t
Temperature value: 32.299999
# ioctrl -v
IO CONTROL Version: 1.0
Compilation Date....: May 14 2013
Compilation Time....: 10:44:47
# ioctrl -p
Power Status: 1, 1, 1, 1
#
```

Notice: The command “ -C “ & “ -T “ are for models 9820 & 9828 only.

C =Current . T =Temperature

## C. Modbus TCP

**Modbus:** We supply the TCP models of ModBus control

TCP Modbus	
Modbus Enable	<input type="checkbox"/>
Port	502
<input type="button" value="Apply"/>	

## D. BACnet TCP

In this section is for development of system integrator who is familiar with Telnet to enable / disable the function and to setup it's port .

BACnet <small>Beta</small>	
Enable	<input type="checkbox"/>
Port	47808
<input type="button" value="Apply"/>	

## 4.4.4. IP SERVICE

In this section , user can setup

- A. IP Server & CNT ( Cross Network Technology ) ,
- B. CNT ( MQTT )

IP Service Setting (Search)	
Enable	<input type="checkbox"/>
IP Service Server :	Server1 ▾
Device Name :	IP_POWER
Country :	Country
City :	City
myipedit login Account	
<a href="#">Find IP_POWER device on myipedit.com</a>	
<input type="button" value="Apply"/>	

CNT(MQTT) Setting (Remote control)	
MQTT Service	IPPower ▾
Enable	<input type="checkbox"/>
Status	
<input type="button" value="Apply"/>	

## A. IP Service & CNT Setting :

The IP SERVICE allow 9850XX to be accessed easily on the internet by our IP Power Center or IP EDIT. With this feature anyone can find its device with no problems.

IP Service Server: Allows user can find user of 9850XX on the internet without having to remember long IP Addresses. Instead user can just remember the name of user device.

IP Service Setting (Search)	
Enable	<input type="checkbox"/>
IP Service Server :	Server1 ▾
Device Name :	Server1 Custom <input type="text"/>
Country :	Country <input type="text"/>
City :	City <input type="text"/>
myipedit login Account	<input type="text"/>
<b>Find IP_POWER device on <a href="http://myipedit.com">myipedit.com</a></b>	
<input type="button" value="Apply"/>	

- Enable : Enable or Disable this function by clicking the small box .
- IP Service Server : use our server or custom server .
- Device name , Country & City :

User can search the 9850XX by Device name , Country or City.

This allows the device to be accessed easily on the Internet, user no longer have to Port Forwarding , user device to be able to use it. Only some devices are CNT compatible.

Please refer page #14 for the function of IP Server


The screenshot shows the IPEdit application window. At the top, there are fields for 'Internet online devices', 'IP Server' (set to 'Server1'), 'Device Name' (set to '9258'), 'Country', and 'City'. A 'Search' button with a magnifying glass icon is highlighted with a red box. Below the search fields, there are 'Connect' and 'Disconnect' buttons. A table below displays the search results:

Device	Name	Country	City	IP ddrss	Port	Mac Address	Serve
9258	IP9258KFB...	USA	Franconia	71.168.75.96	80	00925800d65f	Serve
9258	IP9258_888...			1.34.95.208	80	009258009380	Serve
9258	IP9258KFB	USA	Franconia	71.168.75.96	8078	009258004a76	Serve




**B. CNT ( MQTT) –**

For developing only. 9850XX supports MQTT fucniton. Please contact with your distributor for the details if you would like to develop own system.



## 4.5 System Setting



### 4.5.1 Management

In this section there are 6 settings: Administrator setting, Language Settings, Web server Setting, NTP settings, Import Configuration files and System Reset.

**System Management**

You may configure administrator account and password, NTP settings, and Dynamic NTP settings here.

Administrator Settings	
Account	<input type="text" value="admin"/> <input checked="" type="radio"/> Admin <input type="radio"/> Operator <input type="radio"/> Viewer
Password	<input type="password"/> <input type="button" value="Apply"/>
Language Settings	
Language	<input type="text" value="English"/> <input type="button" value="Apply"/>
Web Server Settings	
Https(Port:443)	<input checked="" type="checkbox"/>
Http	<input checked="" type="checkbox"/>
Enable Self Signed Certificate	<input type="checkbox"/>
<input type="button" value="Apply"/>	
NTP Settings	
Date	<input type="text" value="01"/> / <input type="text" value="01"/> / <input type="text" value="1970"/> (MM/DD/YY)
Time	<input type="text" value="00"/> : <input type="text" value="49"/> : <input type="text" value="00"/> (HH:MM:SS) <input type="button" value="Apply"/>
Current Time	<input type="text" value="Thu Jan 1 08:49:00 GMT 1970"/> <input type="button" value="Sync with local time"/>
Time Zone	<input type="text" value="GMT+0800/China/Beijing"/> <input type="button" value="Apply"/>
NTP Server	<input type="text" value="pool.ntp.org"/> ex: time.nist.gov
Sync with NTP	Every <input type="text" value="1"/> hours <input type="button" value="Apply"/>
Import configuration files	
Location	<input type="text" value="選擇檔案"/> <input type="button" value="Import"/>
System reset	
Export configuration file	<input type="button" value="Apply"/>
Factory Reset	<input type="button" value="Apply"/>
Reboot	<input type="button" value="Apply"/>

## Administrator setting

In this section allows user to change password for 3 different authorization level. The account name and password can be changed, but each Authorities only support one Account name & one password.

**1. Administrator (Admin):** The *Administrator* has the authority to create other users, remove users, and control the device. 9850XX will ask to log in again if change the Default Setting here.

**2. Operator:** The operator can only control the setting of “ IO Control “ section but can not see other page of 9850XX .

**3.Viewer:** The viewer can only see the “ IO Control “ section , but can not see other page of 9850XX.

Default Setting of the Authorities :

Authority	Account name	Password
Admin	Admin	12345678
Operator	user	User
Viewer	guest	Guest
Note	Please amend the password as number or English character from 1 to 8 characters. <b>Do not use special symbol like “ ” ; : ~ ! @ # \$ % ^ &amp; * ( )</b>	

Please click “Apply “ button after change the account name / password

## Language Settings

There are 3 language option of 9850XX .The default language is English.  
The other two languages are “Traditional Chinese “ and “ Simple Chinese “ .

## Web Server Settings

There are 3 options to setting Web server. (1) http (2) https (3) self-signed certificate  
Http and Https are quite simple, just click on the icon to enable or disable it.

If you click the self-signed certificate, it will show two options of the certificate we provide,  
Choose the certificate you want in one of the options.

## NTP setting

In this section, user can setup the date , time , current time , time zone , NTP server and sync with NTP to get the time synchronization .

NTP Settings	
Date	01 / 23 / 2018 (MM/DD/YY)
Time	14 : 49 : 22 (HH:MM:SS) <input type="button" value="Apply"/>
Current Time	Tue Jan 23 14:49:21 GMT 2018 <input type="button" value="Sync with local time"/>
Time Zone	[(GMT+0800)ChinaCoast,HongKong ▼]
NTP Server	pool.ntp.org ex: time.nist.gov
Sync with NTP	Every 1 hours <input type="button" value="Apply"/> <input type="button" value="Cancel"/>


SYNC with NTP : User can setup the time gap ( 1~300 hours ) for 9850XX to check the time with the NET server .

## Import configuration file

To setup multiple with same setting , user can import the settings of other 9850XX from a “ DAT “ file which is exported form another 9850XX . By import this file to other 9850XX device and shorten the setup time .

Import configuration files	
Location	<input type="button" value="選擇檔案"/> 未選擇任何檔案 <input type="button" value="Import"/> <input type="button" value="Cancel"/>

As press “ Import “, there is caution message show as following :



Before click “ Ok “ to import , please do read following notice :

- Do NOT import DAT file which is not export form 9850XX. The warranty will be invalidated if any wrongdoing from “ Import “ .
- Please do Import the file in LAN / Ethernet . To avoid Import fail , please do not Import file via Internet

## System rest

User can click one button to set back the setting to default or restart the 9850XX without device nearby user side.

**Note :** The factory default setting of 9850XX IP is assigned by DHCP. It will change the IP if load factory defaults .

System reset	
Export configuration file	<input type="button" value="Apply"/>
Factory Reset	<input type="button" value="Apply"/>
Reboot	<input type="button" value="Apply"/>

- Export configuration file : Export the settings into DAT file for import to other 9850XX
- Factory Reset : set back to factory default .
- Reboot : 9850XX device power reboot

## 4.5.2 System Information

User can get the system information here.

System Information			
<b>System</b>			
System Up Time	0 days 0 hour 2 min 55 sec	MAC Address	00:76:58:00:4E:C0
Firmware Version	v1.29_710	Hardware Version	4.4.1.7
<b>WAN</b>			
WAN IP Address	0.0.0.0	Ethernet Port	80
Default Gateway	192.168.1.1	Internet Port	80
Primary DNS	168.95.1.1	Secondary DNS	8.8.8.8
<b>LAN</b>			
Connected Type	DHCP		
Local IP Address	192.168.1.168		
Local Netmask	255.255.255.0		
<b>VPN</b>			
IP Address	0.0.0.0		
<b>Other Information</b>			
SNMP	Disable		
ModBusTCP	Disable		
BacnetIP	Disable		
Telnet	Enable		
UPNP	Disable		
IPSERVICE(Search)	Disable		
CNT(Remote control)	Disable		
Rotation System	Disable		
Http	Enable		
PPTP	Disable		

## 4.5.3 System Log

In this section , user can get the 9850XX system operation information and send the information to assign Server IP address ( not support name ) . **The system information will be deleted after 9850XX device power reboot.**

### System Log

Syslog:  
**Syslog Server IP Address**

#### System Log:

```
Jan 23 18:16:04 IP_POWER syslog.info syslogd started: BusyBox v1.12.1
Jan 23 18:16:04 IP_POWER kern.notice kernel: klogd started: BusyBox v1.12.1 (2017-12-07 01:17:44
Jan 23 18:16:04 IP_POWER kern.alert kernel: [ 9.016000] PROC INIT OK!
Jan 23 18:16:04 IP_POWER kern.err kernel: [ 9.780000] gre: can't add protocol
Jan 23 18:16:04 IP_POWER kern.err kernel: [ 19.024000] ### raeth: can not open udhcpc_eth.pid
```

Please click the IP and save by click “ Apply ”

## 4.5.4 Firmware

Please only use the file supply from Aviosys distributor or Aviosys .

There are two sections: Bootloader & Firmware

The firmware update function only support in LAN connection .

Before update, please DO [READ](#) THE HI-LITE MESSAGE BLOW:

Bootloader: This function is about to update hardware and control driver, it works with firmware but not change all the time.

**It takes about 1 minute to upload upgrade flash and be patient please. Caution! A corrupted image will hang up the system.**

Upgrade Firmware

Upgrade selected firmware to obtain new functionality. **Caution! A corrupted image will hang up the system.**  
It takes about 1 minute to upload & upgrade flash and be patient please.

Version: Old

**Update Bootloader**

Location:  未選擇任何檔案

Apply

**Firmware**

Location:  未選擇任何檔案

Apply

To update the 9850XX, please follow the instruction below to prevent anything happens like **update incomplete** or **hardware disable** which may be caused by wrongdoing of updating:

- 1) Turn off all chat programs including ( Skype, FB, QQ, AIM, Yahoo messenger ....etc.)
- 2) Check to make sure that all devices are turned on safely and powered
- 3) While updating do not turn off the power
- 4) Make sure that the cable is connected firmly
- 5) Do not interrupt the update process, the update must be completely finished .
- 6) Turn off, any Spyware or antivirus software which may conflict with the update.
- 7) Update firmware in the Local Area Network (LAN)
- 8) Support update under 32bit Web Browser ( 32 bit version only ) like IE, Google Chrome,  
**Do not use browser at 64 bit version**
- 9) Please change the PORT as 80
- 10) **Reboot and Do the Hardware Reset** ( keep pressing RESET button for 10secs ) after update successfully.
- 11) **Clear the Cookies from the temporary file of PC** to avoid get the old webpage .

Please also update the notice in webpage before update:

## 5. Other ways to control

Besides web page control, there are several ways to control the outlets: by HTTPS/CGI command or by Telnet. 9850XX also support SNMP (MIB), Modbus/TCP and BACnet/TCP.

Please check page #46 to check and enable the function.

### 5.1 CGI HTTP Commands

CGI Commands allow you to easily integrate the 9850XX with other systems and programs. Please read the instructions carefully on how to use the Http:// Commands

To use http:// Commands open up a web browser and type in the command that you would like to use.

1. User authorization. There are 3 formats:

For example: IP address 192.168.1.18, Username: admin, Password: 12345678

1.1 <http://admin:12345678@192.168.1.18/set.cmd?cmd=getpower>

1.2 <http://192.168.1.18/set.cmd?user=admin+pass=12345678+cmd=getpower>

The above 2 way also for HTTPS

2. Command

set.cmd?cmd=

All command do not separate capital / lower case, the connect symbol between commands can be "+", "&" and "?".

2.1 To get firmware version: getversion

<http://192.168.1.18/set.cmd?cmd=getversion>

System return: CGI Command: Data follows  
Version=9258W\_N\_v1.0.0.1

2.2 To get MACAddress: getmac

<http://192.168.1.18/set.cmd?cmd=getmac>

System return: CGI Command: Data follows  
mac=00929000008F



2.3 To get the status of power on/ off : getpower

<http://192.168.1.18/set.cmd?cmd=getpower>

System return :

CGI Command : Data follows

p61=0, p62=0, p63=0, p64=0

P61 to P64 means : POWER1 to POWER4

2.4 To set the power on / off : setpower&p6x=0 or 1

p6x=0 means off , p6x=1means ON , x can be 1 to 4 ( power1 to power 4)

Example : Turn on POWER1 and POWER2 and turn off POWER3 :

<http://192.168.1.18/set.cmd?cmd=setpower&p61=1&p62=1&p63=0>

System return : CGI Command : Data follows

p61=1,p62=1,p63=0

2.5 Setup power to reboot as RESET : setpowercycle& p6x=delayTime

X can be 1to 4 ( power 1 to power 4 ) , ; dealyTime mean the time ( second) waiting for reset

For example :

<http://192.168.1.18/set.cmd?cmd=setpowercycle> &p61=5&p62=2&p63=4

System return : CGI Command : Data follows

p61 cycle ok,p62 cycle ok,p63 cycle ok

## 5.2 Telnet Control

Please enable the telnet function in “Application “ → “ Communication “

Or Check page #46 to check and enable the function .

TELNET:	
Enable	<input checked="" type="checkbox"/>
<input type="button" value="Apply"/>	

```
C:\> Telnet 192.168.1.18
IP login: admin
Password:
```

```
C:\> Telnet 192.168.1.18
#
# ioctrl -h
**-----**
Usage: ioctrl
[-h | --help ].....: display this help
[-s | --setpower p6=0011 or p6x=1(x=1,2,3,4)].....: turn on/off ports on the d
evice
[-p | --getpower ]..: get the on/off status of the device
[-c | --current ].....: get the current value of the device
[-t | --temp ].....: get the temperature value of the device
[-v | --version ].....: display version information
-----
# ioctrl -s p6=1111
p61 ok,p62 ok,p63 ok,p64 ok,
# ioctrl -c
Current value: 0.000000, 0.000000, 0.000000, 0.000000
# ioctrl -t
Temperature value: 32.299999
# ioctrl -v
IO CONTROL Version: 1.0
Compilation Date....: May 14 2013
Compilation Time....: 10:44:47
# ioctrl -p
Power Status: 1, 1, 1, 1
#
```

Notice: The command “ -C “ & “ -T “ are for models 9820 & 9828 only .

C =Current . T =Temperature

## 6.FAQ :

### Q1: Why can't I see the 9850XX's IP address in IPEDIT.exe ?

Ans.: Please check the PC you use is under same LAN/ network / segment as 9850XX . Please turn off some Anti-Virus / online chatting software .

If there are more than 1 network card , include dynamic network card , please disable one and make sure the one you selected is Under the same segment with IP9850XX.

Please refer the following possible parts for this 9850XX not been searched by IPEDIT

- Boot up successfully : Please reboot the 9850XX and check if there are 1 short beep after 3 seconds . This beep means the device boot up successfully . If not , the device may have issue.
- Network card : Please check if there are more than two network card – include wire / wireless / dynamic - in the PC which used IPEDIT software . IPEDIT only support single network PC , please disable the other network connection / functions.
- Anti Virus software / Firewall : Please turn off the antivirus software firewall temporary.
- Power : If there is no power go to 9850XX , please check the fuse part . There will be no power for 9258 if the fuse buttons is pop up - not easy/flexible to press as it was – by over loading for long time , please press the fuse back and the power will go to 9258 to boot up .
- 6. Connection : Please make sure that the 9850XX is under same router with the PC used IPEDIT . It is fine to connect across multiple routers but it need to setup the MASK part which need some knowhow .

### Q2 : Why can't I receive e-mail ?

Ans.: Please check the DNS and GATEWAY setting first ( Check user router or ask user ISP company ) .There is a test button for checking the setting success or fail to send e-mail.

### Q4: How can I reset to default:

Ans : Keep pressing the button of "RESET for 10 seconds at least

To reset to original manufacture settings : press the reset button with a sharpen pin for 10 seconds then RELEASE. There will be 3 beeps sound which means reset start and 9850XX will be rebooted itself -there is one beep after reboot ) and most information go back to default setting ( LAN IP ).